

Handset Sharing, DECT Server 2500/8000

# Configuration Guide

## **Copyright Notice**

© 2013 Spectralink Corporation All rights reserved. Spectralink™, the Spectralink logo and the names and marks associated with Spectralink's products are trademarks and/or service marks of Spectralink Corporation and are common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Spectralink.

All rights reserved under the International and pan-American Copyright Conventions. No part of this manual, or the software described herein, may be reproduced or transmitted in any form or by any means, or translated into another language or format, in whole or in part, without the express written permission of Spectralink Corporation.

Do not remove (or allow any third party to remove) any product identification, copyright or other notices.

## **Notice**

Spectralink Corporation has prepared this document for use by Spectralink personnel and customers. The drawings and specifications contained herein are the property of Spectralink and shall be neither reproduced in whole or in part without the prior written approval of Spectralink, nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith.

Spectralink reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult Spectralink to determine whether any such changes have been made.

NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS DOCUMENT INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE, OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY SPECTRALINK FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY OF SPECTRALINK WHATSOEVER.

Spectralink Corporation,  
2550 55th Street,  
Boulder CO 80301,  
USA

Spectralink Europe ApS,  
Langmarksvej 34,  
8700 Horsens,  
Denmark

# Contents

<b>Handset sharing on DECT Server 2500/8000 . . . . .</b>	<b>2</b>
<b>Installing Handset Sharing license . . . . .</b>	<b>2</b>
<b>Setting up users and shared lines for handset Sharing . . . . .</b>	<b>2</b>
<b>System settings on DECT Server 2500/8000 for Handset Sharing . . . . .</b>	<b>3</b>
Multi charger only: (default setting is enabled) . . . . .	3
Number of simultaneous users: (default setting is 1) . . . . .	3
Timeout for simultaneous users (minutes): (default setting is 5 minutes) . . . . .	3
Timeout for line assignment (hours): (default setting is 24 Hours) . . . . .	3
Out of charger text (Enter DN/Extension): (default text: Enter DN/Extension) . . . . .	3
Out of charger text (Failed: re-enter DN): (default text: Failed: re-enter DN) . . . . .	4
Out of charger text (Enter password): (default text: Enter password) . . . . .	4
Out of charger text (Failed: re-enter password) : (default text: Failed: re-enter password) . . . . .	4



## *Setting up users and shared lines for handset Sharing*

When setting up handsets and shared lines for handset sharing, you must distinguish between the two parts in the Handset sharing that consists of the handset(s) and the shared line(s). They have to be created separately in the web configuration under Users and Create New Registration.

The detailed description on how this is preformed is found in the Web guide on [www.spectralink.com](http://www.spectralink.com) or in the help files in the web configuration pages under Users.

## *System settings on DECT Server 2500/8000 for Handset Sharing*

After installing the Handset sharing license, some settings can be modified in the DECT Server. This is done in the web based management system in the menu under "System/Configuration". Here you find the Section "Handset sharing" and you can modify the option listed below.

### **Multi charger only: (default setting is enabled)**

To start the login or logout procedure when a handset is placed in or lifted from a Spectralink Multicharger only. When this box is checked, using a single desk charger it will **not** start the login/logout procedure, it will only charge the handset. If the box is left blank, the procedure will also start when a single charger is used.

### **Number of simultaneous users: (default setting is 1)**

In the number of simultaneous users drop down box, select the number of users that can be logged in as the same SIP user (line number) simultaneously. There can be a maximum of 3 users selected.

### **Timeout for simultaneous users (minutes): (default setting is 5 minutes)**

In the Timeout for simultaneous users (minutes) field, enter the number of minutes that should elapse before handset assignment to the same shared line is unassigned. The timer starts when a shared handset is assigned to a shared line. During the specified period the shared handset will co-exists. When the time has elapsed the oldest handset will be logged out and the handsets display will return to standby text.

Values that can be entered into the field is from 0 to 240 minutes. If set to 0 the timer will not be started.

### **Timeout for line assignment (hours): (default setting is 24 hours)**

In the Timeout for line assignment (hours) field, enter the number of hours that should elapse before handset assignment to a shared line is unassigned. The timer starts when a shared handset is assigned to a shared line. When the time has elapsed the handset will be logged out and the handsets display will return to standby text.

Values that can be entered into the field is from 0 to 24 hours. If set to 0 the timer will not be started.

**Out of charger text (Enter DN/Extension): (default text: Enter DN/Extension)**

In the Out of charger text (Enter DN/Extension) text field, enter the message that will be displayed when a user lifts the handset from a charger and has to enter a DN/extension of a shared line in the same group.

**Out of charger text (Failed: re-enter DN): (default text: Failed: re-enter DN)**

In the Out of charger text (Failed: re-enter DN) text field, enter the message that will be displayed if the entered DN/extension is incorrect or if it is not in the same handset sharing group.

**Out of charger text (Enter password): (default text: Enter password)**

In the Out of charger text (Enter password) text field, enter the message that will be displayed when a user has successfully entered the DN/extension and has to enter the password or pin. The password is the DECT access code configured for the shared line. If the DECT access code field for the shared line is empty, the system access code will be used (if any configured). The system access code can be configured in the System Configuration under DECT security).

**Out of charger text (Failed: re-enter password): (default text: Failed: re-enter password)**

In the Out of charger text (Failed re-enter password) text field, enter the message that will be displayed when a user enters an incorrect password.

©2013 Spectralink Corporation. All rights reserved.

Specifications subject to change without notice.

Spectralink Corporation  
2560 55th Street  
Boulder CO 80301, USA  
Spectralink Europe ApS

Spectralink Europe ApS  
Langmarksvej 34  
DK-8700 Horsens  
Tel. +45 7560 2850

[infodk@spectralink.com](mailto:infodk@spectralink.com)  
[www.spectralink.com](http://www.spectralink.com)