

Technical Bulletin CS-12-32

Supporting the Calendar, Instant Messaging and Presence Features on Spectralink 84-Series Handsets

This technical bulletin shows you how to integrate Microsoft® Outlook, Microsoft® Office Communication Server 2007 R2, Microsoft® Lync™ 2010 and, Microsoft® Lync™ 2013 with Spectralink 84-Series handsets. This technical bulletin shows you how to set up the Calendaring, Instant Messaging, and Presence features on the same Spectralink 84-Series handsets.

This document includes the following sections:

- Introduction
- Supporting the Instant Messaging and Presence Features
- Supporting the Calendar Feature

This document is intended for system administrators who plan to support the Calendar, Instant Messaging, and Presence features on your existing Spectralink 84-Series handsets.

System Affected

This technical bulletin applies to:

- For the Calendar feature:
 - Spectralink 84-Series handsets running software version 4.0.0 or later
- For the Instant Messaging and Presence features:
 - Spectralink 84-Series handsets running software version 4.0.0 or later

Description

You can support the following features on Spectralink 84-Series handsets:

Instant Messaging and Presence features This feature enables users to see their contacts' presence—or availability—from their phone. Using the Microsoft Office Communications Server 2007 R2 or Microsoft Lync-based feature, users will also be able to send instant messages to their contacts. Viewing a contact's presence enables users to see if a contact is busy or away from their desk before they send a message.

Calendar feature This feature enables users to access and view their Microsoft Outlook calendar information directly from their phone. Users can also set up meetings, join meetings, and view meeting notifications from their phone.

In the following sections, you'll learn which components you need to install and how to configure each feature.

Supporting the Instant Messaging and Presence Features

You can support the Instant Messaging and Presence features on the Spectralink 84-Series handsets.

Assembling the Required Software Elements

The following tables show the Spectralink and Microsoft products you require to support the Instant Messaging and Presence features on your handsets.

Table 1: Spectralink Products Required for Instant Messaging and Presence

Product	Version	Description
API	N/A	The instant messaging client that is implemented on the phone is based on the following reference documents available from Microsoft: [MS-PRES]: Presence Protocol Specification [MS-SIPREGE]: Session Initiation Protocol (SIP) Registration Extensions [MS-SIPRE]: Session Initiation Protocol (SIP) Routing Extensions [MS-SIP]: Session Initiation Protocol Extensions You can search for these documents in the Open Specifications section of the Microsoft Developers Network (MSDN) Library .

Table 2: Microsoft Products Required for Instant Messaging and Presence

Product	Version	Description
Microsoft® Active Directory®	2003 or 2008	Enables account logins and integrates with Office Communications Server 2007 R2, Microsoft Lync Server 2010 and Microsoft Lync Server 2013. Note: Spectralink products currently support only a single-forest Active Directory deployment.
Microsoft® Certificate Authority	N/A	Issues certificates for the Active Directory forest.

<i>Product</i>	<i>Version</i>	<i>Description</i>
Microsoft® SQL Server®	N/A	Stores phone information in a database for users to access.
Microsoft® Lync™ Server	2010 or 2013	Provides presence-based, real-time instant messaging, as well as voice, video, and data communications.

Deploying the Instant Messaging and Presence Features

To deploy the Instant Messaging and Presence features, you'll need to install and configure several Microsoft products. To enable and use the features on Spectralink 84-Series handsets, do the following:

1. Update each phone's configuration file(s).
2. Define login credentials for each phone user.
3. Add contacts to each phone's local contact directory.

Updating Each Phone's Configuration File

On your phones' provisioning server, update each phone's configuration file(s) to enable the features and set additional parameters. For example, update the **features.cfg** and/or **wireless.cfg** files.



Note

When you create configuration files for your organization, Spectralink recommends that you use the software configuration template files—part of all software deliverables—as a guide to how configuration files should look and which parameter values to use.

The following table shows the parameters you need to set to support the Instant Messaging and Presence features.

<i>Parameter</i>	<i>Permitted Values</i>	<i>Default</i>
feature.messaging.enabled¹	0 or 1	0
If 0, the instant messaging feature is disabled. If 1, the feature is enabled.		
feature.presence.enabled¹	0 or 1	0
If 0, the presence feature — including buddy managements and user status — is disabled. If 1, the presence feature is enabled with the buddy and status options.		
reg.x.address	<IMUsername>@<LyncHostName>. <LyncDomainName>	Null
The user part (for example, 1002) or the user and the host part (for example, 1002@company.com) of the registration SIP URI or the H.323 ID/extension. For these features, the user's instant messaging (IM) identity.		

<i>Parameter</i>	<i>Permitted Values</i>	<i>Default</i>
reg.x.auth.password	string	Null
The password to be used for authentication challenges for this registration. If the password is non-Null, it will override the password entered into the Authentication submenu on the Settings menu of the phone. For these features, the Lync Server authentication password.		
reg.x.auth.userID	string	Null
User ID to be used for authentication challenges for this registration. If the password non-Null, it will override the user parameter entered into the Authentication submenu on the Settings menu of the phone. For these features, the Lync Server authentication name.		
reg.x.server.y.address	dotted-decimal IP address or hostname	Null
The IP address or host name of a SIP server that accepts registrations. If not Null, all of the parameters in this table will override the parameters specified in <code>voIpProt.server.*</code> . Note: If this parameter is set, it will take precedence even if the DHCP server is available. If this registration is used for Microsoft Office Communications Server 2007 R2 this parameter must be in the form <code>OCShostname.OSCdomain_name</code> . Note: The Office Communications Server or Lync Server address must be resolvable by DNS or local DNS static routing definitions.		
reg.x.server.y.specialInterop	standard, ocs2007r2, lcs2005, lync2010	standard
Specify if this registration should support Microsoft Office Communications Server 2007 R2 (ocs2007r2), Microsoft Live Communications Server 2005 (lcs2005), or Microsoft Lync 2010 (lync2010). Note: To use instant messaging set this parameter to ocs2007r2 or lync2010.		
reg.x.server.y.transport	DNSnaptr, TCPpreferred, UDPOnly, TLS, TCPOnly	DNSnaptr
The transport method the phone uses to communicate with the SIP server. Null or DNSnaptr – if <code>reg.x.server.y.address</code> is a hostname and <code>reg.x.server.y.port</code> is 0 or Null, do NAPTR then SRV look-ups to try to discover the transport, ports and servers, as per RFC 3263. If <code>reg.x.server.y.address</code> is an IP address, or a port is given, then UDP is used. TCPpreferred – TCP is the preferred transport; UDP is used if TCP fails. UDPOnly – only UDP will be used. TLS – if TLS fails, transport fails. Leave port field empty (will default to 5061) or set to 5061. TCPOnly – only TCP will be used. The protocol to use for communications with the Office Communications Server or Lync Server. ‘TLS’ is the recommended setting.		
roaming_buddies.reg	positive integer	Null
The index of the registration which has roaming buddies support enabled. If Null, the roaming buddies feature is disabled.		
roaming_privacy.reg	positive integer	Null
Specify the index of the registration/line that has roaming privacy support enabled. If Null, roaming privacy is disabled.		
messaging.quickNotes.x	String of up to 128 characters	Null
Up to 10 (x =1 to 10) quick notes for use in instant messages		

¹ Change causes phone to restart or reboot.

Defining Login Credentials for Phone Users

To view presence information on a Spectralink 84-Series phone, users must define login credentials using the phone's main menu. Once you have defined a user's login credentials, the phone can connect to the Microsoft Office Communications Server or Microsoft Lync Server to display presence, and users can send instant messages to their contacts.

To define login credentials:

1. From the home screen, select **Settings**.
2. From the Settings screen, select **Basic Settings > Login Credentials**.
3. From the Login Credentials screen, enter the user's domain, user name, and password.

Adding Instant Message Contacts

For each handset, add contacts to the IM Contacts list or the local contact directory. Users will be able to see presence information for the contacts in their network. If users define an IM address for a contact in their network, users can send instant messages to the contact directly from the contact directory.

You can define an IM address as **<username>@<domain>** or **<username>**. If you define it as **<username>**, the domain name will be the value specified for the instant messaging registration line.

Supporting the Calendar Feature

You can support the Calendar feature on the Spectralink 84-Series handsets.

Assembling the Required Software Elements

The following tables show the licenses and products you require to integrate the Calendar feature on your phones.

<i>Product</i>	<i>Version</i>	<i>Description</i>
Microsoft Active Directory	2003 or 2008	Enables account logins and integrates with Microsoft® Exchange Server. Note: Spectralink 84-Series handsets currently support only a single-forest Active Directory deployment.
Microsoft SQL Server	N/A	Stores phone information in a database for users to access.

<i>Product</i>	<i>Version</i>	<i>Description</i>
Microsoft Exchange Server	2007 SP3 2010 2012	Hosts mailboxes and calendars. As a minimum configuration for the Calendar feature to work on your phones, you can accept the default configuration. Note: Exchange Server 2007 and 2010 includes Microsoft Exchange Web Services (EWS), which enables client applications to communicate with the Microsoft Exchange Server. Make sure EWS is enabled. For more information about EWS, see the Exchange Web Services Reference available from the MSDN Library .

Deploying the Calendar Feature

To deploy the Calendar feature, you'll need to install and configure the Microsoft products. Once you have installed the required products, you will need to do the following:

1. Update each phone's configuration file.
2. Define login credentials for each phone user.

Updating Each Phone's Configuration File

On your phones' provisioning server, update each phone's feature configuration file (for example, **features.cfg**) to configure the feature.



Note

When you create configuration files for your organization, Spectralink recommends that you use the software configuration template files—part of all software deliverables—as a guide to how configuration files should look and which parameter values to use.



Note

You can use the Web Configuration Utility to change the Calendar parameters. To enable Microsoft Exchange Calendar Integration and configure the settings, navigate to Settings > Applications and expand Exchange Applications.

The following table shows the parameters you need to set to enable the Calendar feature and provide access to the EWS interface for your phones.

<i>Parameter</i>	<i>Permitted Values</i>	<i>Default</i>
exchange.meeting.phonePattern	String	Null
The pattern used to identify phone numbers in meeting descriptions, where "x" denotes any digit and " " separates alternative patterns (for example, xxx-xxx-xxxx/604.xxx.xxxx).		

Parameter	Permitted Values	Default
Note: You can use this parameter in locations other than North American if the numbers you use numbers that look like 7 or 10 digits phone numbers, or if you use tel: URIs in the meeting descriptions. For example, in the meeting description, enter a meeting phone number as (0098) 216 602 0855 or tel:00982166020855.		
exchange.meeting.reminderEnabled	0 or 1	1
If 0, meeting reminders are disabled. If 1, they are enabled.		
exchange.server.url¹	String	Null
The Microsoft Exchange server address. For example, enter the Exchange Server Web Services OOF URL.		
feature.exchange.Calendar.enabled¹	0 or 1	0
If 0, the calendaring feature is disabled. If 1, the feature is enabled.		

¹Change causes phone to restart or reboot.



Admin Tip

To find the Microsoft Exchange Server URL, see the tip at http://www.msexchange.org/articles_tutorials/exchange-server-2007/management-administration/configuring-exchange-server-2007-web-services-urls.html.

Defining Login Credentials for Phone Users

To view personal calendar information on a Spectralink 84-Series handset, you must define user's login credentials and users must enter these login credentials using the phone's user interface. Once a user's login credentials are entered, the phone can connect to the Microsoft Exchange Server and display the user's calendar information.

To define login credentials:

1. From the home screen, choose **Settings**.
2. From the Settings screen, choose **Basic Settings > Login Credentials**.
3. From the Login Credentials screen, enter the user's domain, user name, and password.

Copyright Notice

© 2012-2014 Spectralink Corporation All rights reserved. Spectralink™, the Spectralink logo and the names and marks associated with Spectralink's products are trademarks and/or service marks of Spectralink Corporation and are common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Spectralink.

All rights reserved under the International and pan-American Copyright Conventions. No part of this manual, or the software described herein, may be reproduced or transmitted in any form or by any means, or translated into another language or format, in whole or in part, without the express written permission of Spectralink Corporation.

Do not remove (or allow any third party to remove) any product identification, copyright or other notices.

Notice

Spectralink Corporation has prepared this document for use by Spectralink personnel and customers. The drawings and specifications contained herein are the property of Spectralink and shall be neither reproduced in whole or in part without the prior written approval of Spectralink, nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith.

Spectralink reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult Spectralink to determine whether any such changes have been made.

NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS DOCUMENT INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE, OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY SPECTRALINK FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY OF SPECTRALINK WHATSOEVER.

Warranty

The *Product Warranty and Software License and Warranty* and other support documents are available at <http://support.spectralink.com>.

Contact Information

US Location

800-775-5330

Spectralink Corporation
2560 55th Street
Boulder, CO 80301

info@spectralink.com

Denmark Location

+45 7560 2850

Spectralink Europe ApS
Langmarksvej 34
8700 Horsens

infodk@spectralink.com