

NetLink i640 Wireless Telephone


Quick Reference Guide

System Feature Activation

The features that have been programmed in your system may be viewed and activated through the Shortcut Menu and Softkey Functions.

Shortcut Menu: Press **MENU** while off hook to display the Shortcut Menu. This menu lists the feature description and any associated shortcut key. As you scroll through the features by pressing the **Up** and **Down** buttons, the feature abbreviation is highlighted in the softkey function display area. To activate a feature, you may press its softkey, its shortcut key, or the **Select** button while the option is highlighted. To activate the feature using its shortcut key, press the shortcut key at any time while in the Shortcut Menu. The feature will activate whether or not that feature is currently displayed or highlighted. No shortcut indicates that the feature does not have a shortcut and this is generally the case with primary level softkey functions. To cancel out of the Shortcut Menu and return to the Main display press **MENU**.

Softkey Functions: There are 16 possible features displayed in the four levels of the softkey function display area. Press **FCN** while off hook to scroll to the next level. Repeat as required. Press the corresponding softkey to activate any feature. While scrolling through the softkey functions, a shortcut key may be pressed to activate its feature, whether or not that feature is currently displayed in the softkey function display area.



NetLink i640 Wireless Telephone

Status/Tone Indicators



The signal strength icon indicates the strength of the signal and can assist the user in determining if the handset is moving out of range.



The voicemail icon indicates that you have a new voicemail message.

No service message

An alarm sounds and a descriptive message displays when the Wireless Telephone cannot receive or place calls. You may be outside of the covered area. Walk back into the covered area. The in-service tone indicates service is re-established.



The battery icon indicates the amount of charge remaining in the Battery Pack. The level indications are approximations of the remaining Battery Pack life. They do not indicate equal amounts of Battery Pack Life. When only one level remains, the Battery Pack needs to be charged.



A left or right arrow is displayed when the screen can be toggled either left or right to display more characters as described above.

Up and down arrows are displayed when the menu has additional options above or below what is shown in the display area.



The download icon displays when the handset is receiving software over the air.

IMPORTANT NOTE:

- It is recommended that standard acceptance procedures be followed prior to operating this equipment in proximity of life-support systems.
- To minimize risk of interference, pacemaker users should not carry the Wireless Telephone next to the pacemaker.
- Earpiece may retain magnetic objects.
- Operation of the Wireless Telephone may produce an audible noise noticeable to hearing aid users. It is recommended that a hearing aid compatible headset be used by hearing aid users.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For information on Battery Packs, usage tips, and care of Wireless Telephones, see the Wireless Telephone User Guide or visit <http://www.polycom.com/usa/en/support/voice/wi-fi/wi-fi.html>.

- Turn on** Press and hold **Power On**. Two chirps will sound. When the key is released, the in-service tone sounds.
- Turn off** Press and hold **Power Off**. One chirp will sound. If in a call, hang up first, then turn off.
- Make a call or go off hook** Press **Start Call**.
- Select line** Press **LINE** and the number key corresponding to the required line.
- Dial number** Press number keys.
- Hang up** Press **End Call**. Be sure to do this at the end of each call.
- Answer call** Press **Start Call**.
- Change volume** While in a call, press the **Up** or **Down** button.
- Silence while ringing** Press the **End Call** key to silence the ring.
- Unlock keypad** Press the **Unlk** softkey then **#**.
- Lock keypad** Press **FCN**, then **Select** to activate **Lock Keys** on the Standby menu.
- Headset answer** Press any key (other than **End Call**, or a softkey) to answer a call when a headset is plugged in.
- Standby menu** Press the **FCN** key while in Standby mode (handset on but not in a call). Press **Up** or **Down** to highlight option, then press **Select** to select the option.
 (If available) From Standby menu select language from list. From Standby menu adjust ring tones, ring volume, ring cadence, and set vibrate options.
 From Standby menu adjust noise mode for background noise, key tones, warning tones, display contrast and keypad Autolock.
- Push-to-talk** (If available) From Standby menu select Push-to-talk to enable push-to-talk and select push-to-talk channel. Press and hold the push-to-talk button while speaking into the microphone to broadcast on the selected channel.
- Backlight** Comes on when any key is pressed. Turns off after ten seconds if no key is pressed.
- Battery release** Squeeze both battery release buttons simultaneously to release Battery Pack.



Please contact your facility's Network Administrator for support.